



<b>Team</b>	<b>Date:</b>
<b>Team Member Number</b>	

**Demerit: 1 demerit for each omission (Order not important)**

<b>For Failure to:</b>	<b>Demerit</b>
------------------------	----------------

1	Prepare the apparatus for disassembly after use	
---	---	--

2	Remove the protective cover	
---	-----------------------------	--

3	Remove the oxygen cylinder	
---	----------------------------	--

4	Detach the breathing hoses from the cooler and CO2 scrubber canister	
---	--	--

5	Detach hoses from connector assembly	
---	--------------------------------------	--

6	Dismantle connector assembly	
---	------------------------------	--

7	Disconnect breathing bag from CO2 scrubber canister	
---	---	--

8	Disconnect pressure relief valve from CO2 scrubber canister	
---	---	--

9	Remove CO2 scrubber canister	
---	------------------------------	--

10	Dismantle CO2 scrubber canister	
----	---------------------------------	--

11	Disconnect breathing bag from air cooler	
----	--	--

12	Disconnect blue medium pressure line from air cooler	
----	--	--

13	Remove air cooler	
----	-------------------	--

14	Remove pressure relief valve	
----	------------------------------	--



# BG4 DIS-ASSEMBLY

15	Dismantle pressure relief valve	
16	Remove breathing bag retaining bar	
17	Remove positive pressure springs	
18	Remove switch box	
19	Disconnect minimum valve from frame	
20	Pull moisture relief valve out of retaining clip on frame	
21	Disconnect yellow, medium pressure line from minimum valve	
22	Remove the breathing bag with the moisture relief valve and minimum valve attached	
23	Re-insert the switch box into the housing on the frame, if the carrying harness is to be disassembled.	
24	Remove the minimum valve from the breathing bag	
25	Remove the moisture relief valve from the breathing bag	
26	Dismantle moisture relief valve	
27	Remove the waist belt	
28	Detach the sentinel from the shoulder strap	
29	Remove the shoulder straps	

**Total Demerits:**

Signature of Judge: