

BG4 UNDER 02

Team		Date:
Team Member:		
Demerit: 2 demerits for each omission, 1 demerit for wrong order Step 1-5 only		
For Failure to:		Demerit
1	Await order from captain	
2	Put on facemask and adjust straps	
3	Test facemask seal	
4	Open oxygen cylinder valve fully and turn back 1/4 turn	
5	Observe sentinel until cylinder pressure is displayed	
Captain's inspection of team member apparatus (order not important)		
6	Head straps and connector assembly (physical check)	
7	Facemask seal	
8	Oxygen cylinder valve (physical for correct position)	
9	Record cylinder pressure before leaving FAB	
10	Check overall condition of the team member (sign or verbal)	
	Total Demerits:	
Signature of Judge		