

MX6 FIELD TEST

Team		Date:	
Team Member:			
Demerit: 2 demerits for each omission, 1 demerit for wrong order			
For Failure	to:	Demerit	
1	Push and hold center button until lights flash		
2	Wait for the screen to display the gases with numbers		
3	Push center button twice to get menu at top of screen		
4	Scroll to sensors with right button		
5	Scroll to calibrate		
6	Push center button		
7	Push OK (unit zeros and calibrates O2, will beep when done)		
8	Push OK		
9	Apply calibration cup when "apply CO" is displayed on screen		
10	Open valve on cal-gas regulator		
11	Allow unit to calibrate each gas separately (done automatic, will beep after each gas is complete)		
12	Record results		
13	Allow unit to alarm		

14	Turn off calibration gas and remove cup		
15	Allow gases to clear		
16	Push center button twice to get menu at top of screen		
17	Clear peaks		
18	Return to operating mode		
19	Report results to captain		
	Total Demerits:		
Signature of Judge			
	5. Val. 686		