



MSA G1 - DONNING ON A CASUALTY

<i>Team</i>	<i>Date:</i>
<i>Team Member:</i>	

Demerit: 2 demerits for each omission, 1 demerit for incorrect order

<i>For Failure to:</i>	<i>Demerit</i>
1 Fully open cylinder valve	
2 Ensure the control module analog display indicates a full cylinder	
3 Put the facepiece on the casualty ensuring harness is sitting correctly on head with no twisting	
4 Adjust facepiece and tighten straps firmly and evenly	
5 Check seal by pressing bottom regulator button	
6 Have patient breathe normal	

Total Demerits:

Signature of Judge