



BG4 FUNCTION TEST

Team	Date:
-------------	--------------

Team Member

Demerit: 2 demerit for each omission
1 demerit for wrong order (step 10-15 only)

For Failure to:	Demerit
------------------------	----------------

1	Perform positive pressure leak test on the Test it 6100	
---	---	--

2	Inspect apparatus and cylinder test date including belts and lanyard	
---	--	--

3	Connect BG4 to Test it 6100	
---	-----------------------------	--

4	Test No Pressure warning	
---	--------------------------	--

5	Test Inhalation Valve	
---	-----------------------	--

6	Test Exhalation Valve	
---	-----------------------	--

7	Test Pressure Relief Valve	
---	----------------------------	--

8	Test Moisture relief valve	
---	----------------------------	--

9	Perform Positive Pressure leak test	
---	-------------------------------------	--

10	Open cylinder	
----	---------------	--

11	Test the bypass and Constant Dosage rate	
----	--	--

12	Test the Minimum Valve Activation pressure	
----	--	--

13	Record Oxygen cylinder pressure and close cylinder	
----	--	--



BG4 FUNCTION TEST

14	Test the Low Pressure alarms	
15	Observe Battery test and shut off Sentinel	
16	Inspect facemask	
17	Install cover	
18	Place date on seal and put on BG4	
19	Put BG4 in storage case	
20	Record all information on test record	

Total Demerits:

--

Signature of Judge:

--