



SSR 90 M DONNING

<i>Team</i>	<i>Date:</i>
<i>Team Member:</i>	

Demerit: 2 demerits for each omission, 1 demerit for wrong order

<i>For Failure to:</i>	<i>Demerit</i>
1 Pull pin on carrying case	
2 Break seal and remove lid	
3 Pull apparatus out by neck strap	
4 Attach facemask or mouthpiece to breathing tube	
5 Put on neck strap	
6 Put on and adjust facemask or mouthpiece and nose clip	
7 Exhale into apparatus	
8 Pull quick start pin	
9 Check facemask seal by squeezing breathing tube	
10 Adjust waist and neck straps	
11 Put unused parts into container and close lid	

Total Demerits:

Signature of Judge